

# Decorative Millwork Installation Guide

**TIP:** Our Decorative Millwork come standard with a ready-to-install, double UV-protective white finish. You can customize your Millwork with latex or oil base paints, faux finishes, gold leaf, sponging, feathering or marbleizing techniques to create your own, one-of-a-kind masterpiece. If you decide to paint, stain or faux finish your Millwork it may work best to do this before installation. This can speed up the project by preventing any spills onto the surrounding wall.

**Other Materials and Tools You Need:** Safety glasses, pencil, polyurethane construction adhesive.

**Other Materials and Tools You May Need:** Ladder, tape measure, caulk or wood filler, sandpaper, latex or oil-based paint.

\* You may not need these materials, depending upon the type of Louver you are installing any your desired result.

- 1 Select the location for installation. Hold the millwork in place and mark the location with a pencil.
- 2 Apply a 1/4" bead of polyurethane construction adhesive to only the portion of the millwork surface that will touch the mounting surface.
- 3 Press the millwork in place using the pencil marks as guides. Fasten securely with the necessary fasteners, then countersink fasteners and fill holes with exterior plastic wood filler.
- 4 Sand the filled holes flush with the millwork surface and touch up with paint.
- 5 If desired, caulk around millwork, filling any gaps between millwork and mounting surface.



For any questions or comments regarding kit instructions, give us a call at: 1.800.294.1098 or email us at: [sales@architecturaldepot.com](mailto:sales@architecturaldepot.com)

[architecturaldepot.com](http://architecturaldepot.com)